

NATIONAL RADIO INSTITUTE MODEL 68 TUBE TESTER

OPERATING INSTRUCTIONS

(Follow in Order Listed)

LINE ADJUSTMENT

- (1) Insert power cord into a 110 volt 60 cycle supply.
- (2) Set "A-CIRCUIT" knob as shown in column "A-CIR."
- (3) Set "B-FILAMENT" knob as shown in column "B-FIL."
- (4) Set "C-LOAD" knob as shown in column "C-LOAD."
- (5) Set levers as shown in column "U-UP" and "D-DOWN."
- (6) Insert tube in socket.
- (7) Turn "LINE" knob until meter pointer reads at "LINE TEST" mark.

SHORT TEST

- (8) Move each lever referred to in light face type on chart (one at a time) two positions and back. For example, type 01-A move levers 2 and 3 to "D" position. A shorted tube is indicated by a bright red glow of the "SHORT TEST" neon lamp.

VALUE TEST

- (9) Hold "TEST" knob in "VALUE" position and read tube condition on meter.
- (10) Release "TEST" knob. Return all levers to center position.

SPECIAL TESTS

OPEN ELEMENT TEST

- (1a) Follow operations (1) through (9).
- (2a) With "Test" knob in "VALUE" position, move each lever in "U" position (only those shown on chart in light face type) to "D" position (one at a time) and return. Continuity between tube pin and the element being tested is indicated by a change in pointer deflection. A small change denotes a satisfactory plate or screen connection. A large change denotes a satisfactory grid connection. When there is only one lever in "U" position, no open element test need be made.
- (3a) Release "TEST" knob.

FILAMENT AND TAP CONTINUITY TEST

- (1b) Follow operations (1) through (7).
- (2b) Set "B-FILAMENT" knob back to .75 position.
- (3b) Move each lever referred to in **dark face** type on chart (one at a time) two positions and back. For example, type 01-A move lever 4 to "U" position. "Good" filament or other internal pin connection is indicated by a bright red glow of the "SHORT TEST" neon lamp.

CONTINUITY TEST (pilot lamps and other miniature base bulbs)

- (1c) Follow operations (1) and (7) under "LINE ADJUSTMENT."
- (2c) Set "B-FILAMENT" knob to voltage of lamp under test.
- (3c) Place lamp in center of 7 prong socket.
- (4c) A "good" lamp is indicated by normal lighting of its filament.

TUBE CHART NOTES

TEST 2 and TEST 3

When more than one test is given on the chart for the same tube type, proceed as noted below:

- (1e) Follow operation (1) through (10)—(first test).
- (2e) Reset all knobs and levers as noted on the chart for Test 2.
- (3e) Hold "TEST" knob in "VALUE" position and read tube condition on meter.
- (4e) Repeat operations (1e), (2e), and (3e) for Test 3.
- (5e) Release "TEST" knob. Return all levers to center position and turn "LINE" knob to "OFF."

Special note on chart refers to the tube directly preceeding note.

Lever markings 1 through 9 designate RMA tube pin numbers 1 through 9 respectively.

Lever "0" designates the Top Cap Connection.

"Good tube reads 5," etc., indicates tubes reading 5 and higher are good.

"Tapped Fil. See Oper. Inst. (1b) to (3b)" is added after the more common tubes with tapped filaments. It is a reminder that filament tap continuity must be checked. For the most accurate check, the FILAMENT AND TAP CONTINUITY TEST should be made on all tubes.

INSTRUCTIONS FOR MAKING CHART LISTINGS

NEW TUBE TYPES

From time to time, supplementary tube data will be available to cover new tube types. Until this data is set up, the following may be used to obtain preliminary chart settings.

Use 3 or more new tubes and proceed as follows:

- (1f) Refer to manufacturer's handbook under the particular tube type for filament voltage and pin connections.
- (2f) Set "A-CIRCUIT" switch as follows:
 - "1" for tubes with cathode current below 4 Ma, generally diode types.
 - "2" for tubes with cathode current from 3 to 15 Ma, generally filament types excluding diodes.
 - "3" for tubes with cathode current above 8 Ma, generally indirectly heated (cathode) types excluding diodes.
 - "4" for target or eye tubes, gaseous rectifiers and gaseous control tubes.
- (3f) Set "B-FILAMENT" switch to filament voltage.
- (4f) Refer to base drawing in "Manufacturer's Handbook" on tubes for the type being set up. Levers "1234, etc." compare to RMA pin numbers.
- (5f) Set all levers in normal or center position. This is one of the "FILAMENT" positions and all elements in this position are tied together.
- (6f) Find the first filament connection pin on tube base and leave corresponding lever in center position. This connects one side of filament to the filament transformer.
- (7f) Find the second filament connection pin on tube base and move corresponding lever to "D" position. This connects the opposite side of the filament to the filament transformer. If filament is tapped at center, move corresponding filament pins to connect the two sections of filament in parallel. If filament has a panel lamp section, move the levers corresponding to this section to "D" position.
- (8f) Find the cathode connection pin on tube base and move corresponding lever to "D" position. This connects the cathode to one side of the filament transformer.
- (9f) If the tube is of the multi-section type such as duodiodes, duotriodes, etc., find the elements not under test and move corresponding levers to "D" position.
- (10f) Move all levers corresponding to the other active elements under test to "U" position.
- (11f) Insert tube into proper socket.
- (12f) Turn on "LINE" control and adjust so that meter reads at "LINE TEST" mark.
- (13f) Hold "TEST" switch in "VALUE" position. Adjust "C-LOAD" control for each tube so that the majority of the new tubes read 70 on the meter scale.
- (14f) List settings in the book for further reference.

GENERAL NOTES

Pointer indication above full scale indicates tube is extremely good or more than 130%. To make element continuity check on these tubes, turn load control "C" so that pointer falls within end scale markings and proceed with continuity tests.

The seven pin sub-miniature socket is used for 5, 6 and 7 prong tubes. Place the red dot on the tube to the extreme right to match the dot on the socket.

Cathode to heater leakage is indicated by a faint glow of the "SHORT TEST" neon lamp when making short test operation (8).

TUBE SUFFIX LETTER SYMBOLS

In general, tubes with suffixes as noted below can be checked by using the set up for the tube without that suffix.

The letter G indicates a glass tube with an octal base.

GT Indicates use of a T-9 bulb.

Y Indicates an "Intermediate loss" base.

The letters A, B, C, D, E, and F used in sequence indicate improved versions unilaterally interchangeable with the prototype or its subsequent versions.

W Indicates a military type and is assigned only on behalf of the armed forces.

ADDITIONAL TUBES

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
00A	2	5	30	23	4	2E41	1	1.2	56	125	6
01A	2	5	45	23	4	2E41 Test 2	1	1.2	95	3	6
0A2	4	Off	40	15	247	(Good tube reads 10)					
(Good tube reads 10)						2E42	1	1.2	56	125	6
0A3/VR75	4	Off	30	5	237	2E42 Test 2	1	1.2	95	3	6
(Good tube reads 10)						(Good tube reads 10)					
0B3/VR90	4	Off	30	5	237	3B4	3	1.2	47	137	5
(Good tube reads 10)						6AL7	1	6.3	40	13456	28
0C3/VR105	4	Off	30	5	237	6AL7 Eye OP ..	4	6.3	0	3	2468
(Good tube reads 10)						6AL7 Eye CL ..	4	6.3	0	3	28
0D3/VR150	4	Off	30	5	237	6AS5	1	6.3	19	2567	13
(Good tube reads 10)						6AN5	3	6.3	17	156	247
1C21	4	Off	45	5	27	6N4	2	6.3	24	157	246
2C51	2	6.3	23	34	26789	6BA7	3	6.3	18	12	35679
2C51 Test 2	2	6.3	23	67	23489	6BA7 Test 2	1	6.3	36	1679	235
2C52	2	12.6	26	45	67	7AK7	3	6.3	28	2346	78
2C52 Test 2	2	12.6	26	12	37	7C4/1203A	2	6.3	33	4	78
2D21	3	6.3	18	1567	24	12A	2	5	26	23	4
2E24	3	3.3	22	350	27	12AV6	3	12.6	19	17	24
(In Short Test, levers 1, 4 and 6 should show short when moved to "U" position)						12AV6 Test 2 ..	1	12.6	44	5	24
2E26	3	6.3	21	350	1246	12AV6 Test 3 ..	1	12.6	44	6	24
2E30	3	3.3	12	1256	34	12AW6	2	12.6	22	1567	24
2E31	1	1.2	25	124	5	(No open element check on lever 5)					
2E32	1	1.2	25	124	5	12BA7	3	12.6	18	12	35679
2E35	1	1.2	27	124	5	12BA7 Test 2 ...	1	12.6	36	1679	235
2E36	1	1.2	27	124	5	12L8G	3	12.6	20	345	27
						12L8G Test 2 ..	3	12.6	22	158	27

ADDITIONAL TUBES

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
12S8	1	12.6	27	60	28	5672	1	1.2	26	124	5
12S8 Test 2	1	12.6	39	3	58	5676	2	1.2	28	13	4
12S8 Test 3	1	12.6	37	1	28	5677	1	1.2	24	13	4
12S8 Test 4	1	12.6	34	4	28	5678	1	1.2	23	124	3
19J6	2	12.6	24	16	37	5691	3	6.3	28	12	37
19J6 Test 2	2	12.6	24	25	37	5691 Test 2	3	6.3	28	45	67
26D6	2	25	22	16	2357	5692	2	6.3	26	12	37
26D6 Test 2	1	25	40	567	123	5692 Test 2	2	6.3	26	45	67
35C5	3	32	20	2567	13	5693	2	6.3	27	3468	57
50C5	3	50	17	2567	13	RK-61	1	1.4	26	13	4
50Y7	3	50	20	3	467	5696	2	6.3	31	16	2457
50Y7 Test 2	3	50	20	5	678	5731	2	6.3	37	4	78
210-T	3	7.5	56	23	4	WL-481	4	2.5	59	0	4
230-S	2	2	35	23	4						
233-S	3	2	39	234	5						
234-S	2	2	40	230	4						
262-B	3	7.5	42	20	34						
274-A	3	5	36	2	4						
274-A Test 2 ...	3	5	36	3	4						
300-B	3	5	21	23	4						
313-CB	4	Off	53	2	14						
313-CD	4	Off	44	2	14						
376-B	4	Off	37	5	27						
393-A	4	2.5	20	40	12						
507-AX	1	1.2	26	124	5						
523AX	1	1.2	25	124	5						
525AX	1	1.2	26	124	5						
526AX	1	1.2	26	124	5						
553AXA	1	1.2	25	124	5						
605CX	2	6.3	22	1257	46						
606BX	2	6.3	23	1	34						
608CX	3	6.3	20	15	46						
619CX	2	6.3	25	14	35						
717-A	1	6.3	23	468	357						
816	4	2.5	19	0	1						
FM-1000	1	6.3	20	25	137						
FM-1000 Test 2 ..	1	6.3	35	46	137						
1229	1	2	25	230	4						
1266	4	Off	95	5	237						
(Good tube reads 10. No open element test on levers 3 and 7. Tube normally shows short in short position.)											
1275	3	5	30	2	34						
1275 Test 2	3	5	30	3	24						
1635	2	6.3	26	34	5678						
1635 Test 2	2	6.3	26	56	3478						
1654	1	1.4	41	0	1						
5516	3	3.3	25	350	27						
5618	3	3.3	21	2346	17						
5651	4	Off	95	15	247						
(Good tube reads 30)											

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
0A4	4	Off	40	7	25	1F7 Test 3.....	1	2	95	4	7
0A4 Test 2.....	4	Off	44	5	27	1F7-GV	1	2	35	360	7
OB2	4	Off	95	15	247	1F7-GV Test 2..	1	2	95	4	7
(Good tube reads 10)						1F7-GV Test 3..	1	2	95	4	7
0Y4	4	Off	22	5	378	1G4	1	1.4	30	35	7
0Z4	4	Off	22	5	38	1G5	2	2	39	345	7
0Z4 Test 2.....	4	Off	22	3	58	1G6	1	1.4	35	34	7
1A3	1	1.4	75	26	37	1G6 Test 2.....	1	1.4	35	56	7
1A4	1	2	28	230	4	1H4	2	2	41	35	7
1A5	2	1.4	50	345	7	1H5	1	1.4	33	30	7
1A6	2	2	50	34	6	1H5 Test 2.....	1	1.4	40	5	7
1A6 Test 2.....	1	2	95	250	6	1H6	1	2	30	36	7
1A7	1	1.4	21	56	7	1H6 Test 2.....	1	2	40	5	7
1A7 Test 2.....	1	1.4	95	340	7	1H6 Test 3.....	1	2	40	4	7
1B3/8016	1	1.2	98	0	1345678	1J5	2	2	38	345	7
(Good Tube Reads 10)						1J6	2	2	39	34	7
(For element test, use levers "7" & "0" only.)						1J6 Test 2.....	2	2	39	56	7
1B4	1	2	27	230	4	1L4	2	1.4	37	236	15
1B4P	2	2	35	230	4	1LA4	2	1.4	40	236	8
1B5	1	2	31	25	6	1LA6	1	1.4	30	34	8
1B5 Test 2.....	1	2	40	4	6	1LA6 Test 2....	1	1.4	95	256	8
1B5 Test 3.....	1	2	40	3	6	(Good Tube Reads 40)					
1B7	1	1.4	26	56	7	1LB4	2	1.4	40	236	8
1B7 Test 2.....	1	1.4	95	340	7	1LB6	1	1.4	32	234567	8
1B8	2	1.4	32	345	7	1LC5	1	1.4	32	2346	58
1B8 Test 2.....	2	1.4	60	60	7	1LC6	1	1.4	32	34	8
1B8 Test 3.....	1	1.4	95	8	7	1LC6 Test 2....	1	1.4	80	256	8
1C5	2	1.4	37	345	7	1LD5	1	1.4	32	236	8
1C6	2	2	42	34	6	1LD5 Test 2....	1	1.4	95	4	8
1C6 Test 2.....	1	2	68	250	6	(Good Tube Reads 20)					
1C7	2	2	41	56	7	1LE3	2	1.4	37	26	8
1C7 Test 2.....	1	2	56	340	7	1LH4	1	1.4	40	26	8
1D5	2	2	39	340	7	1LH4 Test 2....	1	1.4	95	4	8
1D5GP	2	2	33	340	7	(Good Tube Reads 20)					
1D7	1	2	31	56	7	1LN5	2	1.4	40	2346	58
1D7 Test 2.....	1	2	95	340	7	1N5	1	1.4	27	340	7
1D8	2	1.4	48	60	7	1N6	2	1.4	38	345	7
1D8 Test 2.....	2	1.4	37	345	7	1N6 Test 2.....	1	1.4	95	6	7
1D8 Test 3.....	1	1.4	95	8	7	(Good Tube Reads 20)					
1E4	2	1.4	45	35	7	1P5	1	1.4	31	340	7
1E5	1	2	35	340	7	1Q5	2	1.4	33	345	7
1E7	2	2	30	348	7	1R4	1	1.5	57	4	78
1E7 Test 2.....	2	2	30	568	7	1R5	1	1.4	21	4	15
1F4	3	2	47	234	5	1R5 Test 2.....	1	1.4	95	236	15
1F5	2	2	36	345	7	1S4	2	1.4	30	2346	15
1F6	1	2	37	230	6	1S5	1	1.4	41	456	7
1F6 Test 2.....	1	2	95	4	6	1S5 Test 2.....	1	1.4	55	3	7
1F6 Test 3.....	1	2	95	5	6	1SA6	2	1.4	30	3468	7
1F7	1	2	35	360	7	1SB6	1	1.4	36	348	7
1F7 Test 2.....	1	2	95	5	7	1SB6 Test 2....	1	1.4	90	5	7

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
1T4	2	1.4	35	236	7	3B7 Test 2	3	1.5	30	67	18
1T5	2	1.4	40	345	7	3C5	2	1.4	34	345	27
1U4	2	1.4	30	236	15	3C6	2	1.4	40	34	18
1U5	2	1.4	40	236	1	3C6 Test 2	2	1.4	40	56	18
1U5 Test 2	1	1.4	66	4	1	3D6	2	1.5	25	236	18
1V	3	6.3	24	2	34	3E6	2	1.5	26	2346	18
1Z2	1	1.4	90	0	257	(Tapped Filament—See Instructions 1b to 3b)					
(Good Tube Reads 30)						3LE4	2	1.4	34	236	18
2A3	3	2.5	28	23	4	3LF4	2	1.5	27	236	18
2A4	3	2.5	25	5	7	(Tapped Filament—See Instructions 1b to 3b)					
2A4 Test 2	3	2.5	25	3	57	3Q4	2	1.4	33	2346	17
(No Short Test)						(Tapped Filament—See Instructions 1b to 3b)					
2A5	3	2.5	36	234	56	3Q5	3	1.4	33	345	27
2A6	3	2.5	26	20	56	(Tapped Filament—See Instructions 1b to 3b)					
2A6 Test 2	1	2.5	40	4	56	3S4	2	1.4	35	2346	17
2A6 Test 3	1	2.5	40	3	56	(Tapped Filament—See Instructions 1b to 3b)					
2A7	2	2.5	32	5	67	3V4	2	1.4	33	236	17
2A7 Test 2	2	2.5	64	2340	67	(Tapped Filament—See Instructions 1b to 3b)					
2B6	2	2.5	95	2	67	4A6	2	2	35	34	8
2B6 Test 2	3	2.5	50	34	57	4A6 Test 2	3	2	46	56	8
2B7	3	2.5	47	230	67	5AZ4	3	5	57	6	8
2B7 Test 2	1	2.5	40	5	67	5AZ4 Test 2	3	5	57	4	8
2B7 Test 3	1	2.5	40	4	67	5R4 (GY)	3	5	34	4	8
2E5	2	2.5	44	23	56	5R4 (GY) Test 2	3	5	34	6	8
2E5 Eye CL	4	2.5	0	24	356	5T4	3	5	35	6	8
2E5 Eye OP	4	2.5	0	4	2356	5T4 Test 2	3	5	35	4	8
2G5	2	2.5	44	23	56	5U4	3	5	35	6	8
2G5 Eye CL	4	2.5	0	24	356	5U4 Test 2	3	5	35	4	8
2G5 Eye OP	4	2.5	0	4	2356	5V4	3	5	25	6	8
2G21	1	1.2	26	1256	37	5V4 Test 2	3	5	25	4	8
2G22	1	1.2	26	1256	37	5W4	3	5	48	6	8
2S/4S	1	2.5	45	3	45	5W4 Test 2	3	5	48	4	8
2S/4S Test 2	1	2.5	45	2	45	5X3	3	5	43	2	4
2V3	1	2.5	96	0	7	5X3 Test 2	3	5	43	3	4
(Good Tube Reads 20)						5X4	3	5	33	5	8
2W3	2	2.5	36	4	8	5X4 Test 2	3	5	33	3	8
2X2/879	4	2.5	52	0	4	5Y3	3	5	57	6	8
2X3	3	2.5	43	4	8	5Y3 Test 2	3	5	57	4	8
2Y2	1	2.5	95	0	4	5Y4	3	5	57	5	7
(Good Tube Reads 40)						5Y4 Test 2	3	5	57	3	7
2Z2	3	2.5	56	2	4	5Z3	3	5	35	3	4
3A4	2	1.4	26	2346	17	5Z3 Test 2	3	5	35	2	4
3A5	2	1.4	30	23	4	5Z4	3	5	27	6	2
3A5 Test 2	2	1.4	30	56	4	5Z4 Test 2	3	5	27	4	2
3A8	1	1.4	36	340	27	6A3	3	6.3	28	23	4
3A8 Test 2	1	1.4	36	56	27	6A4/LA	3	6.3	36	234	5
3A8 Test 3	1	1.4	45	8	27	6A5	2	3.3	26	35	27
3B5	2	1.4	35	345	27	(Tapped Filament—See Instructions 1b to 3b)					
(Tapped Filament—See Instructions 1b to 3b)						6A6	3	6.3	36	23	47
3B7	3	1.5	30	23	18	6A6 Test 2	3	6.3	36	56	47

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
6A7	2	6.3	30	45	67	6AS7 Test 2....	3	6.3	16	45	68
6A7 Test 2....	2	6.3	38	230	67	6AT6	1	6.3	20	17	23
6A8	2	6.3	31	56	78	6AT6 Test 2....	1	6.3	35	5	23
6A8 Test 2....	2	6.3	40	340	78	6AT6 Test 3....	1	6.3	35	6	23
6AB5	2	6.3	95	23	56	6AU6	2	6.3	22	1256	47
6AB5 Eye CL...	4	6.3	0	24	356	6AV6	3	6.3	19	17	24
6AB5 Eye OP...	4	6.3	0	4	2356	6AV6 Test 2....	1	6.3	44	5	24
6AB6	3	6.3	62	45	378	6AV6 Test 3....	1	6.3	44	6	24
6AB6 Test 2....	3	6.3	44	35	478	6B4	3	6.3	28	35	7
6AB7	3	6.3	23	468	357	6B5	3	6.3	45	24	356
6AC5	3	6.3	34	35	78	6B5 Test 2....	3	6.3	63	34	256
6AC6	2	6.3	30	35	78	6B6	3	6.3	32	30	78
6AC6 Test 2....	3	6.3	35	45	78	6B6 Test 2....	1	6.3	40	4	78
6AC7	3	6.3	21	468	357	6B6 Test 3....	1	6.3	40	5	78
6AD6	2	6.3	95	345	78	6B7	3	6.3	50	230	67
(Good Tube Reads 15)						6B7 Test 2....	1	6.3	40	4	67
6AD6 Eye CL...	4	6.3	0	346	78	6B7 Test 3....	1	6.3	40	5	67
6AD6 Eye OP...	4	6.3	0	5	3478	6B8	3	6.3	45	360	78
6AD7	3	6.3	33	345	78	6B8 Test 2....	1	6.3	40	4	78
6AD7 Test 2....	2	6.3	51	16	78	6B8 Test 3....	1	6.3	40	5	78
6AE5	3	6.3	29	35	78	6BA6	2	6.3	23	1256	47
6AE6	2	6.3	33	35	78	6BD6	2	6.3	12	1256	47
6AE6 Test 2....	2	6.3	33	45	78	6BE6	2	6.3	22	1	24
6AE7	2	6.3	26	34	57	6BE6 Test 2....	2	6.3	22	567	24
6AE7 Test 2....	2	6.3	27	36	78	6BF6	3	6.3	28	17	2456
6AF5	2	6.3	24	35	78	6BF6 Test 2....	1	6.3	38	5	12467
6AF6	2	6.3	95	345	78	6BF6 Test 3....	1	6.3	38	6	12457
(Good Tube Reads 15)						6BG6	3	6.3	19	580	37
6AF6 Eye CL...	4	6.3	0	345	78	6BJ6	2	6.3	22	1567	24
6AF6 Eye OP...	4	6.3	0	5	3478	6C4	2	6.3	25	156	47
6AG5	3	6.3	20	156	237	6C5	2	6.3	30	35	78
6AG7	3	6.3	24	468	57	6C6	1	6.3	21	230	456
6AH7	3	6.3	30	13	27	6C7	1	6.3	21	20	67
6AH7 Test 2....	3	6.3	30	56	47	6C7 Test 2....	1	6.3	40	4	67
6AJ5	2	6.3	23	156	237	6C7 Test 3....	1	6.3	40	5	67
6AK5	2	6.3	22	156	237	6C8	2	6.3	27	30	47
6AK6	3	6.3	30	1256	37	6C8 Test 2....	2	6.3	27	56	78
6AL5	1	6.3	23	7	14	6D4	3	6.3	20	17	45
6AL5 Test 2....	1	6.3	23	2	45	6D5	3	6.3	32	35	78
6AL6	3	6.3	24	450	78	6D6	3	6.3	21	2340	56
6AQ5	3	6.3	22	1567	24	6D7	2	6.3	28	230	467
6AQ6	1	6.3	20	17	23	6D8	2	6.3	34	56	78
6AQ6 Test 2....	1	6.3	40	5	23	6D8 Test 2....	2	6.3	42	340	78
6AQ6 Test 3....	1	6.3	40	6	23	6E5	2	6.3	36	23	56
6AQ7	1	6.3	22	45	12368	6E5 Eye CL...	4	6.3	0	24	356
6AQ7 Test 2....	1	6.3	34	3	128	6E5 Eye OP...	4	6.3	0	4	2356
6AQ7 Test 3....	1	6.3	34	1	28	6E6	3	6.3	31	23	47
6AR5	3	6.3	12	156	24	6E6 Test 2....	3	6.3	31	56	47
6AR6	3	6.3	20	357	18	6E7	2	6.3	28	230	467
6AS7	3	6.3	16	12	38	6F4	2	6.3	22	1456	78

(Use Adapter BR)

ADDITIONAL TUBES

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
6F5	1	6.3	20	40	78	6Q7 Test 3	1	6.3	47	5	78
6F6	3	6.3	32	345	78	6R6	3	6.3	41	350	78
6F7	3	6.3	43	230	67	6R7	3	6.3	37	30	78
6F7 Test 2	3	6.3	82	45	67	6R7 Test 2	1	6.3	33	4	78
6F8	2	6.3	24	30	47	6R7 Test 3	1	6.3	33	5	78
6F8 Test 2	2	6.3	24	56	78	6S6	3	6.3	24	140	78
6G5	2	6.3	36	23	56	6S7	2	6.3	28	340	578
6G5 Eye CL	4	6.3	0	24	356	6S8	1	6.3	28	60	27
6G5 Eye OP	4	6.3	0	4	2356	6S8 Test 2	1	6.3	40	1	27
6G6	3	6.3	36	345	78	6S8 Test 3	1	6.3	40	4	27
6G7	3	6.3	36	20	357	6S8 Test 4	1	6.3	40	3	57
6G7 Test 2	1	6.3	24	4	37	6SA7	2	6.3	24	45	678
6G7 Test 3	1	6.3	24	6	37	6SA7 Test 2	2	6.3	28	348	167
6H4	1	6.3	26	4	78	6SB7Y	2	6.3	22	45	167
6H5	2	6.3	36	23	56	6SB7Y Test 2	1	6.3	34	348	567
6H5 Eye CL	4	6.3	0	24	356	6SC7	3	6.3	33	23	67
6H5 Eye OP	4	6.3	0	4	2356	6SC7 Test 2	3	6.3	38	45	67
6H6	1	6.3	25	3	47	6SD7	3	6.3	23	468	357
6H6 Test 2	1	6.3	25	5	78	6SE7	2	6.3	23	468	357
6H7S	3	6.3	33	234	67	6SF5	1	6.3	20	35	27
6H7S Test 2	2	6.3	52	50	67	6SF7	3	6.3	30	246	37
6J4	2	6.3	20	1567	24	6SF7 Test 2	1	6.3	40	5	37
6J5	2	6.3	24	35	78	6SG7	3	6.3	19	468	357
6J6	1	6.3	18	16	47	6SH7	2	6.3	20	468	357
6J6 Test 2	1	6.3	18	25	47	6SJ7	2	6.3	27	468	357
6J7	2	6.3	29	340	1578	6SK7	3	6.3	34	468	357
6J8	2	6.3	25	340	78	6SL7	3	6.3	28	12	37
6J8 Test 2	2	6.3	25	56	78	6SL7 Test 2	3	6.3	28	45	67
6K5	1	6.3	20	30	78	6SN7	2	6.3	26	12	37
6K6	3	6.3	34	345	78	6SN7 Test 2	2	6.3	26	45	67
6K7	2	6.3	32	340	578	6SQ7	1	6.3	20	26	37
6K8	1	6.3	20	56	78	6SQ7 Test 2	1	6.3	40	4	37
6K8 Test 2	1	6.3	22	340	578	6SQ7 Test 3	1	6.3	40	5	37
6L5	2	6.3	26	35	78	6SR7	2	6.3	30	26	37
6L6	3	6.3	27	345	78	6SR7 Test 2	1	6.3	50	4	37
6L7	2	6.3	56	4	78	6SR7 Test 3	1	6.3	50	5	37
6L7 Test 2	2	6.3	26	350	78	6SS7	3	6.3	30	468	357
6N5	1	6.3	37	23	56	6ST7	2	6.3	28	26	37
6N5 Eye CL	4	6.3	0	24	356	6ST7 Test 2	1	6.3	95	4	37
6N5 Eye OP	4	6.3	0	4	2356	6ST7 Test 3	1	6.3	95	5	37
6N6	3	6.3	61	45	378	6SU7	2	6.3	25	45	12368
6N6 Test 2	3	6.3	41	35	478	6SU7 Test 2	2	6.3	25	12	34568
6N7	3	6.3	29	34	78	6SV7	2	6.3	23	246	38
6N7 Test 2	3	6.3	29	56	78	6SV7 Test 2	2	6.3	28	5	38
6P5	2	6.3	30	35	78	6SZ7	1	6.3	21	26	38
6P7	2	6.3	32	450	28	6SZ7 Test 2	1	6.3	50	4	38
6P7 Test 2	3	6.3	70	67	28	6SZ7 Test 3	1	6.3	50	5	38
6Q6	1	6.3	20	30	78	6T5	1	6.3	24	23	56
6Q6 Test 2	1	6.3	90	5	78	6T5 Eye CL	4	6.3	0	24	356
6Q7	1	6.3	21	30	78	6T5 Eye OP	4	6.3	0	4	2356
6Q7 Test 2	1	6.3	47	4	78	6T6M	2	6.3	22	340	78

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
6T7	1	6.3	20	30	78	7AB7	3	6.3	26	135	4678
6T7 Test 2	1	6.3	40	4	78	7AD7	3	6.3	17	2346	578
6T7 Test 3	1	6.3	40	5	78	7AF7	2	6.3	25	34	278
6T8	3	6.3	26	89	357	7AF7 Test 2	2	6.3	25	56	278
6T8 Test 2	1	6.3	26	2	357	7AG7	2	6.3	22	236	4578
6T8 Test 3	1	6.3	26	1	357	7AH7	2	6.3	21	2346	78
6T8 Test 4	1	6.3	26	6	357	7AJ7	2	6.3	23	236	478
6U5	2	6.3	37	23	56	7B4	1	6.3	22	26	78
6U5 Eye CL	4	6.3	0	24	356	7B5	3	6.3	29	236	78
6U5 Eye OP	4	6.3	0	4	2356	7B6	2	6.3	25	23	478
6U6	3	6.3	24	345	78	7B6 Test 2	1	6.3	58	5	478
6U7	2	6.3	30	340	578	7B6 Test 3	1	6.3	58	6	478
6V4	3	6.3	26	2	45	7B6LM	3	6.3	31	23	478
6V4 Test 2	3	6.3	26	3	45	7B6LM Test 2	1	6.3	58	5	478
6V6	3	6.3	29	345	178	7B6LM Test 3	1	6.3	58	6	478
6V7	3	6.3	46	0	78	7B7	2	6.3	28	236	478
6V7 Test 2	1	6.3	50	4	78	7B8	2	6.3	28	34	78
6V7 Test 3	1	6.3	50	5	78	7B8 Test 2	2	6.3	34	256	78
6W5	3	6.3	25	3	78	7C4/1203-A	2	6.3	33	4	78
6W5 Test 2	3	6.3	25	5	78	7C5	3	6.3	29	236	78
6W6	3	6.3	21	345	78	7C5LT	3	6.3	29	236	78
6W7	1	6.3	20	340	578	7C6	3	6.3	33	23	478
6X4	3	6.3	25	1	47	7C6 Test 2	1	6.3	40	5	478
6X4 Test 2	3	6.3	25	6	47	7C6 Test 3	1	6.3	40	6	478
6X5	3	6.3	28	3	78	7C7	1	6.3	22	236	478
6X5 Test 2	3	6.3	28	5	78	7E5	2	6.3	34	1357	468
6X6	2	6.3	41	5	78	7E6	2	6.3	27	23	478
6X6 Eye CL	4	6.3	0	34	578	7E6 Test 2	1	6.3	45	5	478
6X6 Eye OP	4	6.3	0	4	3578	7E6 Test 3	1	6.3	45	6	478
6Y5	3	6.3	28	3	46	7E7	3	6.3	36	256	78
6Y5 Test 2	3	6.3	28	5	46	7E7 Test 2	1	6.3	40	3	78
6Y6	3	6.3	19	345	78	7E7 Test 3	1	6.3	46	4	78
6Y7	3	6.3	33	34	78	7F7	1	6.3	20	34	28
6Y7 Test 2	3	6.3	33	56	78	7F7 Test 2	1	6.3	20	56	78
6Z3	3	6.3	24	2	34	7F8	2	6.3	22	13	47
6Z4	3	6.3	26	2	45	7F8 Test 2	2	6.3	22	68	57
6Z4 Test 2	3	6.3	26	3	45	7G7	2	6.3	24	236	478
6Z5	3	6.3	25	3	14	7G8	2	6.3	24	234	5678
6Z5 Test 2	3	6.3	25	5	14	7G8 Test 2	2	6.3	24	357	2468
6Z7	3	6.3	32	34	78	7H7	2	6.3	24	236	478
6Z7 Test 2	3	6.3	32	56	78	7J7	2	6.3	30	345	78
6ZY5	3	6.3	36	3	78	7J7 Test 2	2	6.3	30	256	78
6ZY5 Test 2	3	6.3	36	5	78	7K7	1	6.3	20	34	28
7A4	2	6.3	24	26	78	7K7 Test 2	1	6.3	39	5	78
7A5	3	6.3	23	236	78	7K7 Test 3	1	6.3	39	6	78
7A6	1	6.3	28	3	28	7L7	2	6.3	26	236	478
7A6 Test 2	1	6.3	28	6	78	7N7	2	6.3	26	34	28
7A7	3	6.3	28	236	478	7N7 Test 2	2	6.3	26	56	78
7A8	2	6.3	35	34	78	7Q7	2	6.3	25	34	78
7A8 Test 2	2	6.3	44	256	78	7Q7 Test 2	2	6.3	41	256	78

TUBE CHART

TUBE TYPE	A Cir	KNOBS B Fil	C Load	LEVER POSITION U Up	D Down	TUBE TYPE	A Cir	KNOBS B Fil	C Load	LEVER POSITION U Up	D Down
7R7	2	6.3	22	256	78	12C8 Test 3	1	12.6	38	5	78
7R7 Test 2	1	6.3	50	3	78	12E5	3	12.6	30	35	78
7R7 Test 3	1	6.3	50	4	78	12F5	1	12.6	22	40	78
7S7	2	6.3	33	34	78	12H6	1	12.6	25	3	47
7S7 Test 2	2	6.3	23	256	78	12H6 Test 2	1	12.6	25	5	78
7V7	3	6.3	18	236	478	12J5	2	12.6	24	35	78
7W7	2	6.3	24	236	4578	12J7	1	12.6	20	340	578
7X7	1	6.3	21	23	478	12K7	3	12.6	34	340	578
7X7 Test 2	1	6.3	20	5	478	12K8	3	12.6	52	340	78
7X7 Test 3	1	6.3	21	6	478	12K8 Test 2	1	12.6	22	56	78
7Y4	3	6.3	33	3	78	12Q7	1	12.6	20	30	78
7Y4 Test 2	3	6.3	33	6	78	12Q7 Test 2	1	12.6	40	4	78
7Z4	3	6.3	49	3	78	12Q7 Test 3	1	12.6	40	5	78
7Z4 Test 2	3	6.3	41	6	78	12SA7	2	12.6	25	45	67
10	3	7.5	56	23	4	12SA7 Test 2	2	12.6	35	38	67
12A5	3	6.3	32	234	56	12SC7	1	12.6	20	23	67
12A6	3	12.6	32	345	78	12SC7 Test 2	1	12.6	20	45	67
12A7	2	12.6	29	230	67	12SF5	1	12.6	20	35	27
12A7 Test 2	1	12.6	20	5	47	12SF7	3	12.6	30	246	37
12A8	2	12.6	36	56	78	12SF7 Test 2	1	12.6	40	5	37
12A8 Test 2	2	12.6	28	340	78	12SG7	3	12.6	19	468	357
12AH7	3	12.6	30	13	27	12SH7	3	12.6	19	468	357
12AH7 Test 2	3	12.6	30	56	47	12SJ7	1	12.6	20	468	357
12AL5	1	12.6	25	34	5678	12SK7	3	12.6	28	3468	57
12AL5 Test 2	1	12.6	25	56	23478	12SL7	3	12.6	28	12	37
12AT6	3	12.6	26	17	23	12SL7 Test 2	3	12.6	28	45	67
12AT6 Test 2	1	12.6	35	5	23	12SN7	2	12.6	29	12	37
12AT6 Test 3	1	12.6	35	6	23	12SN7 Test 2	2	12.6	29	45	67
12AT7	2	6.3	24	12	39	12SQ7	1	12.6	22	26	37
12AT7 Test 2	2	6.3	24	67	89	12SQ7 Test 2	1	12.6	50	4	37
12AU6	2	12.6	22	1256	47	12SQ7 Test 3	1	12.6	50	5	37
12AU7	2	6.3	25	12	345	12SR7	3	12.6	37	26	37
12AU7 Test 2	2	6.3	25	67	458	12SR7 Test 2	1	12.6	33	4	37
12AX7	1	6.3	20	12	345	12SR7 Test 3	1	12.6	33	5	37
12AX7 Test 2	1	6.3	20	67	458	12SY7	2	12.6	32	138	67
12B6	3	12.6	31	30	78	12SY7 Test 2	2	12.6	26	45	67
12B6 Test 2	1	12.6	58	4	78	12Z3	3	12.6	25	2	34
12B6 Test 3	1	12.6	58	5	78	12Z5	3	6.3	25	2	34
12B7/14A7	2	12.6	30	2346	78	12Z5 Test 2	3	6.3	25	6	45
12B8	2	12.6	26	340	17	12Z5/6Z5	3	6.3	25	3	14
12B8 Test 2	3	12.6	26	58	67	12Z5/6Z5 Test 2	3	6.3	25	5	14
12BA6	2	12.6	22	1256	47	14	2	12.6	30	230	45
12BD6	2	12.6	27	1256	47	14A4	2	12.6	26	26	78
12BE6	2	12.6	24	1	24	14A5	3	12.6	33	236	78
12BE6 Test 2	2	12.6	24	567	24	14A7/12B7	2	12.6	30	2346	78
12BF6	2	12.6	34	17	24	14AF7	3	12.6	25	34	25678
12BF6 Test 2	1	12.6	38	5	24	14AF7 Test 2	3	12.6	25	56	23478
12BF6 Test 3	1	12.6	38	5	24	14B6	1	12.6	20	23	478
12C8	3	12.6	41	360	78	14B6 Test 2	1	12.6	40	5	478
12C8 Test 2	1	12.6	38	4	78	14B6 Test 3	1	12.6	40	6	478

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
14B8	2	12.6	34	34	78	25AC5	3	25	31	35	78
14B8 Test 2	2	12.6	30	256	78	25B5	3	25	37	24	56
14C5	3	12.6	25	236	78	25B5 Test 2	3	25	46	34	256
14C7	2	12.6	28	236	478	25B6	3	25	23	345	78
14E6	3	12.6	31	23	478	25B8	2	25	25	340	17
14E6 Test 2	1	12.6	65	5	478	25B8 Test 2	2	25	25	58	67
14E6 Test 3	1	12.6	65	6	478	25C6	3	25	25	345	78
14E7	2	12.6	28	256	78	25D8	2	25	26	56	17
14E7 Test 2	1	12.6	58	3	78	25D8 Test 2	2	25	26	340	17
14E7 Test 3	1	12.6	58	4	78	25D8 Test 3	1	25	22	8	17
14F7	1	12.6	20	34	28	25L6	3	25	22	345	78
14F7 Test 2	1	12.6	20	56	78	25N6	2	25	30	345	78
14F8	3	12.6	22	13	47	25S	1	2	31	25	6
14F8 Test 2	3	12.6	22	68	57	25S Test 2	1	2	40	4	6
14H7	2	12.6	22	236	478	25S Test 3	1	2	40	3	6
14J7	2	12.6	32	345	678	25X6	3	25	27	3	47
14J7 Test 2	3	12.6	33	256	78	25X6 Test 2	3	25	27	5	78
14N7	2	12.6	26	34	28	25Y4	3	25	25	5	78
14N7 Test 2	2	12.6	26	56	78	25Y5	3	25	30	2	36
14Q7	2	12.6	25	34	78	25Y5 Test 2	3	25	30	5	46
14Q7 Test 2	2	12.6	30	256	78	25Z5	3	25	25	2	36
14R7	1	12.6	18	256	78	25Z5 Test 2	3	25	25	5	46
14R7 Test 2	1	12.6	50	3	78	25Z6	3	25	24	3	47
14R7 Test 3	1	12.6	50	4	78	25Z6 Test 2	3	25	24	5	78
14S7	2	12.6	28	34	78	26	2	1.5	36	23	4
14S7 Test 2	2	12.6	24	256	78	26A6	2	25	22	1256	47
14W7	2	12.6	22	236	4578	26A7	2	25	20	345	27
14X7	1	12.6	20	23	478	26A7 Test 2	2	25	20	158	27
14X7 Test 2	1	12.6	20	5	478	26C6	3	25	30	17	2456
14X7 Test 3	2	12.6	24	6	478	26C6 Test 2	1	25	36	5	12467
(Good Tube Reads 30)						26C6 Test 3	1	25	36	6	12457
14Y4	3	12.6	28	3	78	27	2	2.5	32	23	45
14Y4 Test 2	3	12.6	28	6	78	28D7	2	25	22	234	68
14Z3	3	12.6	25	2	34	28D7 Test 2	2	25	22	357	68
15	2	2	36	230	45	28Z5	3	12.6	38	3	187
17	3	12.6	40	23	45	28Z5 Test 2	3	12.6	38	6	47
18	3	12.6	31	234	56	(Tapped Filament—See Instructions 1b to 3b)					
19	3	2	37	23	6	29	2	2.5	36	23	456
19 Test 2	3	2	39	45	6	30	2	2	35	23	4
19T8	3	25	22	89	123567	31	2	2	40	23	4
19T8 Test 2	1	25	17	2	1356789	32	2	2	42	230	4
19T8 Test 3	1	25	17	6	1235789	32L7	3	32	21	345	78
19T8 Test 4	1	25	17	1	2356789	32L7 Test 2	3	32	18	6	17
20	2	6.3	48	23	4	33	3	2	39	234	5
20J8	1	12.6	22	56	78	34	2	2	40	230	4
20J8 Test 2	1	12.6	20	340	78	35	2	2.5	30	230	45
22	2	3.3	56	230	4	35A5	3	32	22	236	78
24A	2	2.5	32	230	45	35B5	3	32	20	1567	24
25A6	3	25	27	345	78	(Shows Short 1 and 7)					
25A7	3	25	27	345	78	35L6	3	32	20	345	78
25A7 Test 2	3	25	23	6	17						

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
35W4	3	32	20	5	467	57	2	2.5	30	230	456
(Tapped Filament—See Instructions 1b to 3b)						57A (AS)	3	6.3	34	230	456
35Y4	3	32	23	2	147	58	3	2.5	35	230	456
(Tapped Filament—See Instructions 1b to 3b)						59	3	2.5	29	2345	67
35Z3	3	32	22	2	78	64	1	6.3	22	230	45
35Z4	3	32	20	5	78	65	2	6.3	28	230	45
35Z5	3	32	21	5	238	67	3	6.3	37	23	45
(Tapped Filament—See Instructions 1b to 3b)						68	3	6.3	37	230	45
35Z6	3	32	20	3	47	70A7	3	70	23	345	678
35Z6 Test 2	3	32	20	5	78	(Shows Short on 1)					
36	2	6.3	32	230	45	70A7 Test 2	3	70	20		167
37	3	6.3	37	23	45	(Allow Tube to Heat Up, Return Levers 6 & 7 to "U" Position. Good Tube Will Kick to 70).					
38	3	6.3	36	230	45	70L7	3	70	25	345	67
39/44	2	6.3	30	230	45	70L7 Test 2	3	70	20	8	17
40	1	5	28	23	4	71A	3	5	47	23	4
40Z5	3	32	20	5	238	75	1	6.3	20	20	56
(Tapped Filament—See Instructions 1b to 3b)						75 Test 2	1	6.3	38	3	56
41	3	6.3	32	234	56	75 Test 3	1	6.3	38	4	56
42	3	6.3	29	234	56	76	2	6.3	33	23	45
43	3	25	31	234	56	77	2	6.3	30	230	456
44	2	6.3	30	230	45	78	3	6.3	31	230	456
45	3	2.5	32	23	4	79	3	6.3	30	23	46
45Z3	3	50	24	26	47	79 Test 2	3	6.3	30	50	46
45Z5	3	32	20	5	238	80	3	5	55	2	4
(Tapped Filament—See Instructions 1b to 3b)						80 Test 2	3	5	55	3	4
46	3	2.5	35	234	5	81	3	7.5	75	2	4
47	3	2.5	41	234	5	82	3	2.5	24	2	4
48	3	32	25	234	56	82 Test 2	3	2.5	24	3	4
49	2	2	38	234	5	82V	3	2.5	24	2	4
50	3	7.5	42	23	4	82V Test 2	3	2.5	24	3	4
50A5	3	50	20	236	78	93	3	5	26	2	4
50B5	3	50	20	236	24	83 Test 2	3	5	26	3	4
50C6	3	50	22	345	78	83V	3	5	24	2	4
50L6	3	50	21	345	78	83V Test 2	3	5	24	3	4
50X6	3	50	19	3	28	84	3	6.3	26	2	45
50X6 Test 2	3	50	19	6	78	84 Test 2	3	6.3	26	3	45
50Y6	3	50	23	3	47	85	3	6.3	45	20	56
50Y6 Test 2	3	50	23	5	78	85 Test 2	1	6.3	47	3	56
50Z6	3	50	21	5	78	85 Test 3	1	6.3	47	4	56
50Z6 Test 2	3	50	21	3	47	86M	3	6.3	37	35	78
50Z7	3	50	25	3	467	87S	2	6.3	33	230	456
50Z7 Test 2	3	50	25	5	678	88	3	5	26	2	4
(Tapped Filament—See Instructions 1b to 3b)						88 Test 2	3	5	26	3	4
51	3	2.5	35	230	45	88M	3	6.3	31	340	578
52	3	6.3	30	234	5	88S	3	6.3	32	230	456
53	3	2.5	32	23	47	89	3	6.3	32	230	56
53 Test 2	3	2.5	32	56	47	89RS	3	6.3	36	20	357
55	2	2.5	32	20	56	89RS Test 2	1	6.3	24	4	37
55 Test 2	1	2.5	40	3	56	89RS Test 3	1	6.3	24	6	37
55 Test 3	1	2.5	40	4	56	95	3	2.5	36	234	56
56	2	2.5	30	23	45						

TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
98	3	6.3	26	2	45	518AX	1	1.2	30	124	5
98 Test 2.....	3	6.3	26	3	45	520AX	1	1.2	30	124	5
99	2	3.3	55	23	4	521AX	1	1.2	30	124	5
113HY/123HY ..	1	1.4	45	23	5	522AX	1	1.2	30	124	5
114HY	3	1.4	55	0	7	585	3	7.5	42	23	4
(Short Top Caps Together)						586	3	7.5	42	23	4
115HY/145HY ..	1	1.4	45	234	5	615HY	3	6.3	33	0	7
117L7	3	110	25	345	78	(Short Top Caps Together)					
117L7 Test 2....	3	110	20	6	17	800	3	7.5	54	0	4
117M7	3	110	23	345	78	(Short Top Caps Together)					
117M7 Test 2....	3	110	21	6	17	801	3	7.5	42	23	4
117N7	3	110	20	345	678	802	3	6.3	29	340	567
117N7 Test 2....	3	110	15		78	807	3	6.3	25	230	45
(Allow Tube to Heat Up. Return Lever 7 to "U" Position. Good Tube Will Kick to 70.)						809	3	6.3	27	30	4
117P7	3	110	22	345	678	812	3	6.3	29	30	4
117P7 Test 2....	3	110	15		78	837	3	12.6	25	340	567
(Allow Tube to Heat Up. Return Lever 7 to "U" Position. Good Tube Will Kick to 70.)						840	2	2	33	230	45
117Z3	3	110	24	15	46	841	3	7.5	45	23	4
117Z4	3	110	19	5	78	842	3	7.5	54	23	4
117Z6	3	110	20	3	47	864	1	1.4	55	23	45
117Z6 Test 2....	3	110	20	5	78	865	3	7.5	80	230	4
123HY/113HY ..	1	1.4	45	23	5	866 (A)	3	2.5	25	0	4
125HY/155HY ..	2	1.4	45	234	5	879	4	2.5	52	0	4
145HY/115HY ..	1	1.4	45	234	5	884	4	6.3	20	35	78
155HY/125HY ..	2	1.4	45	234	5	885	4	2.5	20	23	45
182-B	3	5	37	23	4	950	3	2	46	234	5
183	3	5	40	23	4	951	2	2	40	230	4
201-B	2	5	45	23	4	954	2	6.3	32	3450	78
201-C	2	5	45	23	4	(Use Adapter BN)					
427	3	2.5	44	23	45	955	2	6.3	30	45	78
482-A	3	5	47	23	4	(Use Adapter BN)					
482-B	3	5	37	23	4	956	2	6.3	30	3450	78
483	3	5	40	23	4	(Use Adapter BN)					
484	3	2.5	32	23	45	957	1	1.2	30	45	78
485	2	2.5	33	23	45	(Use Adapter BN)					
486	2	3.3	48	23	45	958	1	1.2	30	45	78
501	1	1.4	35	234	5	(Use Adapter BN)					
501X	1	1.4	35	345	7	959	1	1.2	34	3450	78
502	1	1.4	35	234	5	(Use Adapter BN)					
502AX	1	1.2	30	124	5	986	3	5	26	2	4
502X	1	1.4	35	345	7	986 Test 2.....	3	5	26	3	4
503	1	1.4	35	234	5	1003	4	Off	22	5	38
503AX	1	1.2	30	124	5	1003 Test 2.....	4	Off	32	3	58
503X	1	1.4	35	345	7	1201	2	6.3	34	1357	468
504	1	1.4	35	234	5	1203	1	6.3	33	4	78
504X	1	1.4	35	345	7	1204	2	6.3	26	135	4678
506AX	1	1.2	30	124	5	1221	1	6.3	22	230	456
507AX	1	1.2	30	124	5	1223	1	6.3	22	340	578
						1231	2	6.3	23	236	478
						1232	2	6.3	24	236	478


TUBE CHART

TUBE TYPE	KNOBS			LEVER POSITION		TUBE TYPE	KNOBS			LEVER POSITION	
	A Cir	B Fil	C Load	U Up	D Down		A Cir	B Fil	C Load	U Up	D Down
1267	4	Off	31	5	27	AG Test 2	3	5	26	3	4
1273	3	12.6	26	236	478	CK-1005	4	6.3	22	5	38
1280	3	12.6	26	236	478	CK-1005 Test 2	4	6.3	22	3	58
1284	3	12.6	25	236	478	G-2	1	2.5	45	3	45
1291/3B7	1	1.5	33	23	18	G-2 Test 2	1	2.5	45	2	45
1291/3B7 Test 2	1	1.5	33	67	18	G-4	1	2.5	45	3	45
1293	2	1.4	32	26	8	G-4 Test 2	1	2.5	45	2	45
1294/1R4	1	1.5	57	4	78	G-84	3	2.5	56	2	4
1299/3D6	2	1.5	25	236	18	GA	3	5	32	234	5
1603	1	6.3	23	230	456	KR-1	3	6.3	24	2	34
1608	3	2.5	24	23	4	KR-5	3	6.3	36	234	5
1610	3	2.5	28	234	5	KR-25	3	2.5	36	234	56
1612	3	6.3	25	40	78	KR-98	3	6.3	26	2	45
1614	3	6.3	24	345	78	KR-98 Test 2	3	6.3	26	3	45
1616	3	2.5	57	0	4	PZ	3	2.5	41	234	5
1619	3	2.5	29	345	78	PZH	3	2.5	36	234	56
1620	1	6.3	22	340	78	R-30	2	2	35	23	4
1621	3	6.3	40	345	78	R-100	3	7.5	43	0	4
1622	3	6.3	27	345	78	(Short Top Caps Together)					
1624	3	2.5	26	230	5	R-200	3	7.5	40	0	4
1625	3	12.6	25	340	67	(Filament Connected from 1 & 4 on 4 Pin Tester Socket to 2 & 4 Pin of Tube—Short Top Caps Together and Connect to Top Cap Lead.)					
1626	3	12.6	32	35	78	RK-33	3	6.3	27	45	67
1629	2	12.6	36	35	78	RK-33 Test 2	3	6.3	27	30	27
1629 Eye CL	4	12.6	0	34	578	RK-34	3	6.3	27	50	47
1629 Eye OP	4	12.6	0	4	3578	(Top Cap Lead on Left Top Cap)					
1631	3	12.6	27	345	78	RK-34 Test 2	3	6.3	27	30	47
1632	3	12.6	22	345	78	(Top Cap Lead on Right Top Cap)					
1633	2	25	28	12	37	VR-75	4	Off	30	5	237
1634	1	12.6	20	23	67	(Good Tube Reads 10)					
1851	3	6.3	20	340	578	VR90-30	4	Off	30	5	237
1852	3	6.3	21	468	357	(Good Tube Reads 10)					
1853	3	6.3	23	468	357	VR-105	4	Off	30	5	237
2050	3	6.3	15	356	78	(Good Tube Reads 10)					
2051	3	6.3	19	356	78	VR-150-30	4	Off	30	5	237
7700	1	6.3	20	230	456	(Good Tube Reads 10)					
8016	1	1.2	98	0	1345678	WX-12	1	1.4	55	23	4
(Good Tube Reads 10)						WND. A	3	6.3	35	23	456
(For element test, use levers "7" & "0" only.)						WND. C	3	2.5	35	23	456
9001	1	6.3	20	156	247	X99	2	3.3	55	23	4
9002	2	6.3	27	156	247	XXB	2	1.4	40	34	18
9003	2	6.3	27	156	247	XXB Test 2	2	1.4	40	56	18
9004	1	6.3	20	4	57	XXD	3	12.6	25	34	25678
(Use Adapter BN)						XXD Test 2	3	12.6	25	56	23478
9005	1	3.3	34	5	478	XXFM	1	6.3	20	23	478
(Use Adapter BN)						XXFM Test 2	1	6.3	27	5	48
9006	1	6.3	25	15	247	XXFM Test 3	1	6.3	27	6	78
AF	3	2.5	24	2	4	XXL	2	6.3	24	26	78
AF Test 2	3	2.5	24	3	4						
AG	3	5	26	2	4						

REPLACEABLE PARTS, 68 NRI

Ref. No.	Quan.	Part Name	Description	Function	Part No.
C1	1	Capacitor	.1 Mfd. 400 DC WV	Series Capacitor	T-2631-P27
G	1	Lamp	Neon, 1/25W, GE	Short Test	T-3024-2
M	1	Instrument	1 Ma. 100 Mv. 327-T	Short Test	T-52-288
R1	1	Resistor	Composition, 100K Ohm, $\pm 20\%$, 1/10W	Indication	T-2602-1/10-100K
R2	1	Resistor	Composition, 250K Ohm, $\pm 10\%$, 1/2W	Current Limiting Neon	T-2601-1/2-250K
R3	1	Resistor	Wirewound, 50 Ohm, $\pm 1\%$	Shunt, Neon, Calib.	T-15-1248
R4	1	Resistor	Variable, 200 Ohm, 5% Tol.	Cathode Return Coupling	T-15-1248
R5	1	Resistor	Wirewound, 450* Ohm, $\pm 1\%$	Load Control	T-16-30
R6	1	Resistor	Wirewound, 1800* Ohm, $\pm 1\%$	Tube Test Shunt Res.	T-15-1249
R7	1	Resistor	Composition, 2500 Ohm, $\pm 5\%$, 10W	Tube Test Shunt Res.	T-15-1251
R8	1	Resistor	Composition, 5K Ohm, $\pm 1\%$, 1/2W	Current limiting	T-15-873
R9	1	Resistor	Composition, 1K Ohm, $\pm 1\%$, 1/2W	Current limiting	T-15-1009
R10	1	Resistor	Wirewound, 1200* Ohm, $\pm 1\%$	Current limiting	T-15-1011
R11	1	Resistor	Composition, 75K Ohm, $\pm 1\%$, 1W	Line Meter Calib.	T-15-1250
R12	1	Resistor	Variable, 175 Ohm, Model B, Ohmite with off position	Line Meter Series	T-15-970
S1	1	Switch	14 Pos., 2 Deck, 4 Active Pos.	Line Control	T-16-29
S2	1	Switch	3 Pos., 1 Deck	Circuit Switch	T-22-81
S3	1	Switch	20 Pos., 1 Deck	Test Switch	T-22-43
S4	10	Switch	3 Pos., Lever, 1 Deck	Filament Switch	T-22-35
T	1	Transformer	110 V, Pri., 22 Sec. taps	Element Switch	T-22-56
X	1	Rectifier	Copper oxide, 1/2 Wave, B/1, Schauer, 2 Lead	Filament & Plate Voltage Supply	T-23-41
	1	Case	With Hardware	Line Meter Rect.	T-2248-1
	1	Cord	Line, 7 ft., black	Tester Housing	T-10-765
	10	Knob	9/16D Round, Black	Connector	T-2566-11-7
	2	Knob	1 1/4" bar, black	Element Switch Knob	T-34-7
	3	Knob	1 1/4" bar red	Switch Knobs	5804
A1	1	Socket	7 prong with pilot socket, black, Amphenol S-7C	Switch Knobs	T-34-8
	1	Socket	Bantam, 6 prong, black, Amphenol 78-6H	Tube Socket	T-2455-48
	1	Socket	9 prong, black, Amphenol 78-A9P	Tube Socket	T-2455-58
	1	Socket	4 prong, black, Amphenol S-4	Tube Socket	T-2455-96
	1	Socket	5 prong, black, Amphenol S-5	Tube Socket	T-2455-4
	1	Socket	6 prong, black, Amphenol S-6	Tube Socket	T-2455-5
	1	Socket	Octal, 8 hole, black, Amphenol 78-8L	Tube Socket	T-2455-6
	1	Socket	Miniature, 7 prong, black, Amphenol 78-7P	Tube Socket	T-2455-8L
	1	Socket	Octal, 8 hole, black Amphenol S-8	Tube Socket	T-2455-59
	1	Socket	Subminiature 5, 6 & 7 prong	Tube Socket	T-2455-8
				Tube Socket	T-2455-80

* Approx. value calibration resistor



WIRING DIAGRAM